










ASSEMBLY GUIDE

INIZIO












1




2






3




4





5




6




7





8










10




11





12







13














service@arozzi.com



support@arozzi.se

